

Picture

 Power LED
System Status LED (Flashing Sys. Ok)
Call In Progress LED
Mute LED
Message LED (IP System Only)
Microphone
Menu Button
Mute (Scrolling Down in Menu)
IP System Function Only (Scrolling Up in Menu)
Monitor Function (View Door Station)
Unlock Door (Press for 2 seconds)
Talk Button (Press Once and Again to end)
Speaker

Basic Operation Manual Model: AR562CH1

Operation

When Receiving a Call

The visitor will press the call button on the outside door station which will ring the intercom, from there you will be able to see the visitor on the monitor screen.

Press the Talk Button(12) on the room station to talk with the visitor for a maximum 90 seconds, pressing the door release button (if an electric latch has been installed to your entry door) will unlock the door near the door station, if you want to end the call you can press the intercom button twice or it will ring out after approximately 40 seconds.

How to adjust settings

You are able to adjust the settings of the intercom (which include the brightness level, contrast, colour, audio volume).

To change these options press the Monitor Function (10) followed by the Menu Button (7), choose desired option and adjust using buttons (8) and (9).

To exit the settings press the Menu Button (7) until it exits the settings.

Warranty

This product is guaranteed against faulty workmanship for up to 12 months from the date of installation. You are entitled to receive the replacement of intercom once an inspection has been made by an authorized person.

This Warranty will become **VOID** if the intercom has been tampered with, damaged, repaired by an unauthorized person or becomes faulty from improper use

*Product specifications and design subject to change without notice

Contact Us

Esprit Network Pty Ltd 5/128 Station Road, Seven Hills NSW 2147 Australia Telephone: (02) 86784989 (Toll Free) 1800 24 27 27 Email: services@espritec.com.au