



Picture

- 1. M Button**—To View Main Menu & Also Press ‘OK’
- 2. Up Button**—To Navigate on Screen
- 3. Down Button**—To Navigate on Screen
- 4. Eye Icon**—To View Door Station Camera & Also Select Close /Exit Screen
- 5. Call Button**— To Talk/ Answer /End Call
- 6. Unlock Button**—To Allow Visitor Access (If feature is available)

Basic Operation Manual

Model: ESPT 4.3-01

Operation

When Receiving a Call

The visitor will press the call button on the outside door station which will ring the handset.

The User can press the Call Button (5) to speak to the visitor. The call Button can be pressed again to end the call or the automatic time allocation to door station of approx. 120 seconds will end the Call.

Main Menu Navigation

Up and down buttons can be used to navigate on the main screen to access (M):

Manual Monitor: To View External Door Station

User Setup: To Adjust Call Tone, Ring Volume, Sound Volume and Key Tone using the Up/Down Navigation Controls (2,3).

Warranty

This product is guaranteed against faulty workmanship for up to 12 months from the date of installation. You are entitled to receive the replacement of intercom once an inspection has been made by an authorized person.

This Warranty will become **VOID** if the intercom has been tampered with, damaged, repaired by an unauthorized person or becomes faulty from improper use

*Product specifications and design subject to change without notice

Contact Us

Esprit Network Pty Ltd
5/128 Station Road, Seven Hills NSW
2147 Australia
Telephone: (02) 86784989
(Toll Free) 1800 24 27 27

Email: services@espritec.com.au