

Basic Operation Manual

Model: AR583CK3

Warranty

This product is guaranteed against faulty workmanship for up to 12 months from the date of installation. You are entitled to receive the replacement of intercom once an inspection has been made by an authorized person.

This Warranty will become **VOID** if the intercom has been tampered with, damaged, repaired by an unauthorized person or becomes faulty from improper use

*Product specifications and design subject to change without notice

Operation

How to Change the User Settings

Press the Monitor Button(4) followed by the Mode button which will allow the change of User Settings.

When Receiving a Call

The visitor will press the Unit number on the outside door station which will ring the Intercom in the Unit

The User can touch the Accept Call Button (6), User will be able to see the visitor on the main display screen, and talk to the visitor for up to 90 seconds

User can press the Unlock/Door Release Button (5) to allow the visitor access

Volume can be adjusted by Pressing Lower Volume(2) or Increase Volume (3)

Picture

1. Mode Button (Services Personal Only)
2. Lower Volume/Mute Button
3. Increase Volume Button
4. Monitor Button
5. Unlock/Door Release Button
6. Accept Call Button

LED DISPLAY

Power LED

Network Busy

Network Connected

Mute LED

Mail (Future Function)

Contact Us

Esprit Network Pty Ltd
5/128 Station Road, Seven Hills NSW
2147 Australia
Telephone: (02) 86784989
(Toll Free) 1800 24 27 27

Email: services@espritec.com.au

